

# CONTENTS

<b>PRODUCT</b> .....	<b>2</b>
<b>1 MODELS LIST</b> .....	<b>2</b>
1.1 OUTDOOR UNITS.....	2
1.2 INDOOR UNIT .....	3
1.3 HYDRO-BOX.....	9
1.4 WATER TANK.....	10
<b>2 NOMENCLATURE</b> .....	<b>11</b>
2.1 NOMENCLATURE OF OUTDOOR UNIT .....	11
2.2 NOMENCLATURE OF INDOOR UNIT.....	11
2.3 NOMENCLATURE OF HYDRO-BOX.....	12
2.4 NOMENCLATURE OF WATER TANK.....	12
<b>3 FUNCTION</b> .....	<b>13</b>
<b>4 PRODUCT DATA</b> .....	<b>14</b>
4.1 PRODUCT DATA OF OUTDOOR.....	14
4.2 PRODUCT DATA OF INDOOR UNIT.....	15
4.3 OPERATION RANGE.....	40
4.4 HYDRO-BOX.....	41
4.5 WATER TANK.....	43
4.6 OPERATING TEMPERATURE RANGE.....	44
<b>5 CORRECTION FOR PRODUCT CAPACITY</b> .....	<b>45</b>
5.1 INTRODUCTION TO CAPACITY CORRECTION .....	45
5.2 CAPACITY CODE.....	45
5.3 FORMULA OF CAPACITY CORRECTION.....	45
<b>6 PRINCIPLE OF WORK</b> .....	<b>48</b>
6.1 SYSTEM FLOWCHART.....	48
6.2 EXPLANATION OF FLOWCHART.....	49
<b>CONTROL</b> .....	<b>51</b>
<b>1 CONTROL OF THE UNIT</b> .....	<b>51</b>
1.1 INTEGRAL CONTROL OF THE UNIT.....	51
1.2 OPERATION FLOWCHART.....	54
<b>2 CONTROL FUNCTION OF THE UNITS</b> .....	<b>68</b>
2.1 CONTROL FUNCTION OF THE OUTDOOR UNIT.....	68
2.2 CONTROL FUNCTION OF INDOOR UNIT .....	72
<b>3 WIRELESS REMOTE CONTROLLER</b> .....	<b>81</b>
<b>4 WIRED CONTROLLER</b> .....	<b>84</b>
4.1 WIRED CONTROLLER OF INDOOR UNIT .....	84
4.2 WIRED REMOTE CONTROLLER FOR HYDRO UNIT.....	86
<b>5 FIELD CONTROLLER</b> .....	<b>97</b>
5.1 FUNCTION .....	97
5.3 DISPLAY VIEW.....	99
5.4 CONNECTION BETWEEN REGION CONTROLLER AND THE UNIT .....	100
<b>6 CENTRALIZED CONTROLLER</b> .....	<b>101</b>
6.1 FUNCTION .....	101
6.2 CASE STUDY.....	101
<b>7 MONITORING SOFTWARE</b> .....	<b>114</b>
7.1 FUNCTION .....	114
7.2 CONNECTION BETWEEN THE COMPUTER AND THE UNIT.....	114
7.3 HARDWARE.....	116
<b>INSTALLATION</b> .....	<b>123</b>
<b>1 PRECAUTIONS FOR INSTALLATION</b> .....	<b>123</b>
1.1 PRECAUTIONS FOR INSTALLATION.....	123
1.2 KEY POINTS OF INSTALLATION.....	124
1.3 FLOW CHART OF INSTALLATION .....	126
2	
<b>2 TOOLS FOR INSTALLATION</b> .....	<b>127</b>

2.1 COMMON TOOLS .....	127
<b>3 SELECTION OF INSTALLATION MATERIAL.....</b>	<b>128</b>
3.1 REFRIGERANTS PIPELINE .....	128
3.2 CIRCULATING PIPE .....	128
3.3 DISCHARGE PIPE FOR CONDENSATE.....	128
3.4 HEAT INSULATING MATERIALS .....	129
3.5 COMMUNICATION WIRE AND CONTROL WIRE.....	129
3.6 POWER CORD.....	129
3.7 SUSPENDER AND BRACKET .....	129
<b>4 INSTALLATION SCHEMATIC DIAGRAM.....</b>	<b>130</b>
4.1 INSTALLATION SCHEMATIC DIAGRAM OF UNITS WITH SIDE AIR OUTLET.....	130
4.2 INSTALLATION SCHEMATIC DIAGRAM OF UNITS WITH TOP AIR OUTLET.....	131
<b>5 INSTALLATION OF OUTDOOR UNIT .....</b>	<b>135</b>
5.1 HOISTING OF UNIT.....	135
5.2 SELECTION OF INSTALLATION SITE.....	137
5.3 DIMENSION AND HOLE SITE.....	138
5.4 SPACE DIMENSION FOR INSTALLATION OF THE UNIT IS SHOWN BELOW. ....	139
<b>6 INSTALLATION OF INDOOR UNIT.....</b>	<b>143</b>
6.1 DUCT TYPE .....	143
6.2 4-WAY CASSETT TYPE UNIT.....	149
6.3 1-WAY CASSETT TYPE UNIT.....	155
6.4 WALL MOUNTED TYPE .....	159
6.5 FLOOR CEILING TYPE .....	161
<b>7 INSTALLATION OF HYDRO-BOX .....</b>	<b>166</b>
7.1 DIMENSION OF HYDRO-BOX.....	166
7.2 INSTALLATION METHOD AND DIMENSION OF HYDRO-BOX .....	166
7.3 CONNECTING PIPE BETWEEN OUTDOOR UNIT AND HYDRO-BOX.....	170
7.4 CONNECTION REQUIREMENTS OF HYDRO-BOX AND WATER TANK .....	170
<b>8 INSTALLATION OF WATER TANK.....</b>	<b>171</b>
8.1 CAUTIONS OF INSTALLATION.....	171
8.2 SELECTION OF INSTALLATION POSITION OF WATER TANK .....	171
8.3 INSTALLATION CAUTIONS .....	171
<b>9 INSTALLATION REQUIREMENTS OF REFRIGERANT PIPING .....</b>	<b>172</b>
9.1 SPECIFICATION .....	172
9.2 ALLOWABLE LENGTH AND HEIGHT DIFFERENCES OF THE REFRIGERANT PIPING BETWEEN THE INDOOR AND OUTDOOR UNITS.....	172
9.3 SELECTION OF Y-TYPE BRANCH PIPE.....	174
9.4 SELECTION OF DIAMETER.....	174
<b>10 INSTALLATION OF REFRIGERANT PIPING .....</b>	<b>175</b>
10.1 FLOW CHART OF INSTALLATION .....	175
10.2 THREE PRINCIPLES OF REFRIGERANT PIPING INSTALLATION .....	176
10.3 INSTALLATION OF METAL EMBEDDED PIPE .....	176
10.4 INSTALLATION OF CARRIAGE OF REFRIGERANT PIPING.....	176
10.5 MANAGEMENT AND MACHINING OF REFRIGERANT PIPING.....	177
10.6 INSTALLATION OF REFRIGERANT PIPING.....	180
10.7 WELDING OF COPPER PIPE.....	183
10.8 CLEANING OF REFRIGERANT PIPING .....	186
10.9 PRESSURE MAINTAINING AND LEAK HUNTING.....	187
10.10 HEAT PRESERVATION OF REFRIGERANT PIPING.....	188
10.11 VACUUM PUMPING .....	190
10.12 REFRIGERANT CHARGE.....	191
<b>11 INSTALLATION OF ELECTRONIC EXPANSION VALVE PARTS.....</b>	<b>193</b>
11.1 DIRECTION REQUIREMENTS .....	193
<b>12 INSTALLATION OF CONDENSATE PIPE.....</b>	<b>194</b>
12.1 MATERIAL QUALITY REQUIREMENTS FOR CONDENSATE PIPE .....	194
12.2 INSTALLATION OF DRAINAGE PIPE FOR DIFFERENT TYPES OF INDOOR UNIT .....	198
12.3 TEST FOR CONDENSATE PIPE .....	202

12.4 REQUIREMENTS OF HEAT PRESERVATION.....	203
<b>13 INSTALLATION OF WATER PIPELINE .....</b>	<b>204</b>
13.1 PIPELINE BETWEEN HYDRO-BOX AND WATER TANK .....	204
13.2 CONNECTING PIPE BETWEEN OUTDOOR UNIT AND HYDRO-BOX.....	205
13.3 CONNECTION REQUIREMENTS OF HYDRO-BOX AND WATER TANK.....	205
13.4 INSTALLATION REQUIREMENTS OF WATER PIPELINE .....	205
<b>14 ELECTRICAL INSTALLATION.....</b>	<b>206</b>
14.1 PRECAUTIONS FOR ELECTRICAL INSTALLATION.....	206
14.2 SPECIFICATIONS OF POWER CORD & CIRCUIT BREAKER .....	207
14.3 WIRING SKETCH MAP .....	207
3	
14.4 DIAL-UP OF UNIT .....	208
<b>15 DEBUGGING OF THE UNIT .....</b>	<b>214</b>
15.1 PREPARATION FOR THE DEBUGGING .....	214
15.2 DEBUGGING OF COOLING MODE.....	215
15.3 DEBUGGING OF HEATING MODE .....	215
15.4 DEBUGGING OF WATER HEATING.....	216
<b>MAINTENANCE .....</b>	<b>218</b>
<b>1 PURPOSE .....</b>	<b>218</b>
<b>2 ROUTINE WORK.....</b>	<b>218</b>
2.1 CLEANOUT OF THE WATER SYSTEM.....	218
2.2 THE CLEANOUT OF FINNED HEAT EXCHANGER .....	218
2.3 DAILY MAINTENANCE .....	218
<b>3 ANTI-FREEZING PROJECT IN WINTER.....</b>	<b>220</b>
3.1 CAUTIONS OF WATER SYSTEM.....	220
3.2 CAUTIONS OF OUTDOOR UNIT .....	220
<b>SERVICING.....</b>	<b>223</b>
<b>1 LIST OF UNIT ERRORS .....</b>	<b>223</b>
1.1 LIST OF ERROR DISPLAY ON WIRED CONTROLLER.....	223
1.2 DISPLAY CODE ON DIGITAL TUBE OF OUTDOOR MAINBOARD .....	226
1.3 DISPLAY OF THE NUMBER OF INDOOR UNITS .....	226
<b>2 FLOW CHART OF TROUBLESHOOTING.....</b>	<b>227</b>
2.1 HIGH-PRESSURE PROTECTION .....	227
2.2 LOW-PRESSURE PROTECTION.....	228
2.3 EXHAUST TEMPERATURE PROTECTION .....	229
2.4 COMPRESSOR OVERCURRENT PROTECTION.....	229
2.4 COMPRESSOR OVERCURRENT PROTECTION.....	230
2.6 WATER-FULL PROTECTION.....	233
2.7 ERROR WITH ROOM SENSOR, TUBE-INLET, TUBE MIDDLE AND TUBE-EXIT SENSOR; ERROR WITH ROOM SENSOR, TUBE-INLET, TUBE MIDDLE AND TUBE-EXIT SENSOR AND EXHAUST / CASING TOP SENSOR; ERROR WITH THE COMPRESSOR BOTTOM SENSOR.....	233
2.8 NO ENERGIZATION TO THE UNIT AND MAINBOARD .....	234
2.9 PFC PROTECTION .....	235
2.10 IPM PROTECTION.....	236
2.11 TRIPPING.....	237
2.12 RADIATOR OVERHEAT PROTECTION .....	238
2.13 OVERVOLTAGE PROTECTION OF DC VOLTAGE .....	239
<b>3 CIRCUIT DIAGRAM.....</b>	<b>240</b>
3.1 INTRODUCTION OF MAJOR ELECTRICAL ELEMENTS .....	240
3.2 WIRING DIAGRAM.....	241
<b>4 DISASSEMBLY AND ASSEMBLY PROCEDURE OF MAIN PARTS .....</b>	<b>254</b>
4.1 INTRODUCTION OF MAIN PARTS .....	254
4.2 OUTDOOR UNIT .....	258
4.3 DISASSEMBLY AND ASSEMBLY OF INDOOR UNIT .....	277
<b>5 EXPLODED VIEWS AND PART LIST.....</b>	<b>288</b>
5.1 OUTDOOR UNIT .....	288
5.2 HYDRO UNIT.....	294

5.3 INDOOR UNIT_EXPLODED VIEW AND PARTS LIST.....	304
---	-----