




ETATRACK[®] 400 *active*

Quick Installation Guide

Content of the box and
“how to assemble the frame”.




Assembly of motor fixation and top of mounting pole:




Fixation clip for PV-Modules

Bearing assembly:



System dimensions, mounting pole and concrete suggestion:



X: Mounting pole dimensions: Outer diameter max. 3,5" (89mm), wall thickness min.: 4mm, length 2m