

## DataTables | Gentallela

ID	Parameter	Value	Menu	type
03-050	Operating mode selection heating	Automatic mode I	Circuit 1-> Operation mode	setpoint*status*
03-091	Remote control available	Yes	Circuit 1-> Preferences-> configuration	setpoint*status*
09-075	Operation mode heat generator	Automatic	Heat pump-> Operation mode	setpoint*status*
03-000	room frost protection temperature	12.0	Circuit 1-> Preferences-> configuration	setpoint*heating
03-001	Base point temperature	20.5	Circuit 1-> Preferences-> heating curve Circuit 1-> Preferences-> configuration	setpoint*heating
03-002	Heating limitation lowering operation (for econom mode)	12.0	Circuit 1-> Preferences-> configuration	setpoint*heating
03-012	Design outside temperature	-20	Circuit 1-> Preferences-> heating curve Circuit 1-> Preferences-> configuration	setpoint*heating
03-013	Design supply temperature	35.0	Circuit 1-> Preferences-> heating curve Circuit 1-> Preferences-> configuration	setpoint*heating
03-021	Heating limit outdoor temperature	14.0	Circuit 1-> Preferences-> target temperature heating Circuit 1-> Preferences-> configuration	setpoint*heating
03-051	Room temp day heating operation	22.0	Circuit 1-> Preferences-> target temperature heating Circuit 1-> Preferences-> configuration	setpoint*heating
03-053	Room temp night Heating operation	20.0	Circuit 1-> Preferences-> target temperature heating Circuit 1-> Preferences-> configuration	setpoint*heating
07-009	Setpoint temperature manual mode	27.0	Circuit 1-> Operation mode Circuit 1-> Preferences-> configuration	setpoint*heating
03-036	Cooling limit outdoor temperature	20.0	Circuit 1-> Preferences-> configuration	setpoint*cooling
03-043	Cooling setpoint	23.0	Circuit 1-> Preferences-> cooling curve Circuit 1-> Preferences-> configuration	setpoint*cooling
03-044	Start point summer	24.0	Circuit 1-> Preferences-> target temperature cooling Circuit 1-> Preferences-> configuration	setpoint*cooling
03-045	Slope summer compensation	0	Circuit 1-> Preferences-> target temperature cooling Circuit 1-> Preferences-> configuration	setpoint*cooling
03-047	Design outside temperature	35	Circuit 1-> Preferences-> cooling curve Circuit 1-> Preferences-> configuration	setpoint*cooling
03-048	Design supply temperature	20.0	Circuit 1-> Preferences-> cooling curve Circuit 1-> Preferences-> configuration	setpoint*cooling
03-054	Room temp day cooling operation	24.0	Circuit 1-> Preferences-> target temperature cooling Circuit 1-> Preferences-> configuration	setpoint*cooling
03-056	Room temp night operation	25.0	Circuit 1-> Preferences-> target temperature cooling Circuit 1-> Preferences-> configuration	setpoint*cooling